

ROYAL EXTREME 3 INSTRUCTION MANUAL

Thank you for purchasing this PDA. Please read this manual carefully to become familiarized with your PDA's many features and to ensure years of reliable operation.

NOTICE

We assume no responsibility for any damage or loss resulting from the use of this manual.

We strongly recommend that separate, permanent printed records be kept of all data. Under certain circumstances, such as exposure to an electrostatic discharge, data may be lost or altered, or the unit may become inoperative until reset. Therefore, we assume no responsibility for data lost or otherwise rendered unusable, whether as a result of improper use, repair, battery replacement, or use after the specified battery life has expired from similar causes.

We assume no responsibility, directly or indirectly, for financial losses or claims from third persons resulting from the use of this product and all of its functions, such as stolen credit card numbers, the loss or alteration of stored data, etc.

This product was not designed to bend or survive extreme pressure or temperatures. Do not carry it in your trouser or pants pockets. When in a bag or briefcase, make sure that it is stationary and well padded and protected. Do not leave or store the PDA in environments where temperature ranges can be extreme.

To provide a longer product life, a flip-top cover is provided with the PDA. This should prevent scratches to the display. Do not apply harsh chemicals or water to the display.

The information provided in this manual is subject to change without notice.

SAFETY TIPS

- Be careful not to scratch the touch screen. Use only the supplied stylus or other plastic-tipped pens designed for a touch-sensitive screen. Never use an actual pen or pencil, fingernails or other sharp objects on the surface of the touch screen.
- The PDA should be protected from rain and moisture. Treat the PDA as you would other electronic devices.
- Do not drop your PDA or subject it to strong impacts.
- Protect your PDA from extreme temperatures.
- The touch screen can be cleaned with a soft cloth lightly moistened with a window cleaning solution. Commercial cleaners are sold separately.


INSTALLING THE BATTERIES

Your new PDA is powered by 3 CR2032 lithium batteries. Before using your new PDA for the first time, you will need to install the batteries. You will find them in the PDA's package. Check the back of the PDA. You will see the battery compartment door. Slide the door lock switch to the unlock position. Remove the battery compartment door. Install the batteries with the + sign on the battery facing you. After you have installed the batteries, put the battery compartment door back on the unit.

IMPORTANT NOTE – YOU MUST LOCK THE BATTERY COMPARTMENT DOOR BEFORE USING THE PDA. YOUR PDA WILL NOT OPERATE UNTIL THE DOOR IS LOCKED IN PLACE BY MOVING THE LOCKING SWITCH TO THE LOCKED POSITION!

To ensure smooth operation you now need to reset the PDA. Insert a pointed object, such as a pencil point or the open end of a paperclip into the RESET hole located on the back of the unit. Press lightly until the PDA displays “ERASE DATA” and “KEEP DATA”. Tap “ERASE DATA” to reset or tap “KEEP DATA” to keep data.


Switching On/OFF

The unit can be switched on or off by touching the  key.

Lower Power Detection

“LOW BATTERY” will be displayed and the unit will turn off automatically if low battery power is detected. Change the batteries to continue using your PDA.

Back Light


Tap the  icon to turn the back light on or off.

Insert & Overwrite

To toggle between insert or overwrite, tap .

Enter Numbers, Alphabets & Symbols:

To toggle between numerical keyboard or alphabetical keyboard, tap .

To enter special symbols, tap .

Navigating Through the Screen Prompts, Messages and Records

You can easily navigate through the different functions and operations by using the cursor keys. You will find 4 cursor keys located directly below the screen, near the on/off key. Simply touch a cursor key to move in the direction indicated on the key. There is also a set of cursor keys located on the touch screen. Tap any of the screen cursor keys to move in the desired direction. For your convenience your PDA has an up/down scroll key on the upper left side of the unit. This scroll key

can be used to quickly move through lists of record by advancing one whole screen of information at a time.

Home Time / World Time :

To enter Clock mode, press **menu** and tap **^** / **v** or **↑** / **↓** to select CLOCK then tap **OK**.

Setting Home Time:

- Tap **edit** to enter the CLOCK edit mode. Screen message “SET” appears on the screen.
 - i. **Editing City/ Place:**
 - Tap place name to start changing the place or city.
 - Toggle between CITY and PLACE to select place or city.
 - Tap **^** / **v** or **↑** / **↓** to select the desired place or city.
 - Tap **OK** to confirm the new setting or tap **esc** to abort the change.
 - ii. **Editing Date:**
 - Tap date to change the date.
 - Enter the date. To change the date format see the System Menu instruction.
 - Tap **OK** to confirm the new setting or tap **esc** to abort the change.
 - If the input value is not valid, a message “INCORRECT” will be displayed.
 - iii. **Editing Time:**
 - Tap time to change the time.
 - Enter the time.
 - Tap **OK** to confirm the new setting or tap **esc** to abort the change.
 - If the input value is not valid, a message “INCORRECT” will be displayed.

World Time Setting:

- In CLOCK mode, toggle HM to WD so that the time changes from home time to world time.
- Tap **edit** to edit location. Toggle between CITY or PLACE to select place or city.
- Tap **^** / **v** or **↑** / **↓** to select the desired place or city.
- Tap **OK** to confirm the new setting or tap **esc** to abort the change.

View Home Time/ World Time:

- To view home time, press menu and select CLOCK to enter clock mode.
- To view world time, enter clock mode and toggle HM to WD.

Daily Alarms

To enter Alarm mode, tap **menu** and tap **^** / **v** or **↑** / **↓** to select ALARM then tap **OK**.

Screen message “ALARM” appears.

- Tap **edit** to edit the daily alarm setting.
- Input the alarm time. If the time setting is in am/ pm format, toggle between AM and PM to select the time setting.
- Tap **OK** to confirm the new setting or tap **esc** to abort the change.
- At the “Alarm” screen, toggle between ON and OFF to switch on or off the new daily alarm setting. The word “Alarm” will be shown.
- A beep tone will sound automatically for 30 seconds at the alarm time. Tap any key to stop the beep tone.

























Phone Book:

Entering new records:

- Tap **phone** to enter phone book.
- Tap **new** to begin new record input.
- There are 2 categories, Business and Personal. Select the desired group by touching group.






Please note: The example shown below assumes you will enter information in every field of the phone record. You do not need to fill in all the fields. If you desire, you can simply enter a name and phone number. **Tap **OK** at any time to save the record.**

- Enter last name in the first line of screen.
- Tap **↓** or **↓** to go to second line and input first name. Screen message “FIRST NAME” appears.
- Tap **↓** or **↓** to go to third line and input company name. Screen message “COMPANY” appears.
- Tap **↑** / **↓** or **↑** / **↓** to go to fourth line and input title. Screen message “TITLE” appears.
- Tap **↑** / **↓** or **↑** / **↓** to go to fifth line and input home telephone number. Screen message “HOME” appears.
- Tap **↑** / **↓** or **↑** / **↓** to go to sixth line and input office telephone number. Screen message “WORK” appears.
- Tap **↑** / **↓** or **↑** / **↓** to go to seventh line and input fax number. Screen message “FAX” appears.
- Tap **↑** / **↓** or **↑** / **↓** to go to the eighth line and input mobile phone number. Screen message “MOBILE” appears.
- Tap **↑** / **↓** or **↑** / **↓** to go to the ninth line and input pager number. Screen message “PAGER” appears.

- Tap  /  or  /  to go to the tenth line and input email address. Screen message “EMAIL” appears.
- Tap  /  or  /  to go to the eleventh line and input address. Screen message “ADDRESS” appears.
- Tap  /  or  /  to go to the twelfth line and input city. Screen message “CITY” appears.
- Tap  /  or  /  to go to the thirteenth line and input state. Screen message “STATE” appears.
- Tap  /  or  /  to go to the fourteenth line and input zip. Screen message “ZIP” appears.
- Tap  /  or  /  to go to the fifteenth line and input note. Screen message “NOTE” appears.
- Tap **OK** at any time to save the inputted record and return to Phone entry screen.

Viewing records:





The records are displayed in the following 2 formats:

- In alphabetical order of company.*
 - In alphabetical order of last name.*
- Toggle  to select the display format.
 - Tap  /  or  /  to select the desired record.
 - Tap **OK** or tap the record directly to read.
 - To view characters which are not displayed tap the corresponding line.





Searching for Records:

Records can be located by searching in the following 2 ways:

1. By typing the first character of the name directly:

- Input the first character of the name directly
- If a matching record is found, the record will be shown. If more than one record is found, tap  /  or  /  to select the desired record. If no matching record is found, the message “NO RECORD” will be displayed on screen and press **esc** to return to the Phone screen.

2. By using **find key:**

- Tap **find** and input string to search
- Tap **OK** to start searching
- If a matching record is found, the record will be shown. If more than one record is found, tap  /  or  /  to select the desired record. If no matching record is found, the message “NO RECORD” will be displayed on screen and press **esc** to return to the Phone screen

Editing records:

- In Phone mode, search for the record to be edited and then tap **edit**.
- Edit the record.
- After editing, tap **OK** to save and return to Phone mode or tap **esc** to quit without saving.

Deleting records:

- In Phone mode, search for the record to be deleted and then tap **del**.
- The screen will display DELETE ?
►DELETE
NOT DELETE

Tap **OK** to delete or tap NOT DELETE to abort the deletion.

Memo

To enter memo mode, touch **menu** and scroll through the menu choices by tapping **^** / **v** or **↑** / **↓** until you see the MEMO/ EMAIL prompt. Tap the MEMO/EMAIL prompt or **OK**.

Entering new records:

- In Memo mode, tap **new** to begin new record input.
- There are 2 categories. Select the desired category.
- Enter the name of receiver or sender in the first line.
- Tap **v** to go to next line to enter subject.
- Tap **v** to go to second line to enter the note.
- Tap **OK** to confirm the new record or tap **esc** to abort.

Viewing records:

The records are displayed in the following 2 formats:

- In ascending order of date.*
- In alphabetical order of note.*

Searching for Records, Editing Records, and Deleting Records

Follow the procedures outline under Phone Mode

ToDo

To enter todo mode, touch **menu** and scroll through the menu choices by tapping **^** / **v** or **↑** / **↓** until you see the TODO prompt. Tap the TODO prompt or **OK**.

Entering new records:






- In Todo mode, tap **new** to begin new record input.

- There are 2 categories. Select the desired category.
- Tap ON: to enter date and tap **OK** to save the setting.
- Toggle priority to define the priority of the job.
- Toggle DONE to indicate the status.
- Tap NOTE to enter note.
- Tap **OK** to confirm the new record or tap **esc** to abort.

Viewing records:

The records are displayed in the following 2 formats:

- In ascending order of priority.*
- In ascending order of date.*

- Touch  to select the display format.
- In the format of ascending order of priority, the first character of each record shows working stage of the job and the second character shows priority of job.
- Tap  /  or  /  to select the desired record.
- Tap **OK** or tap the record directly to read.
- To view characters which are not displayed tap the corresponding line directly.

Searching for Records, Editing Records, and Deleting Records

Follow the procedures outline under Phone Book Mode.

Planner:


Entering new records:

- Tap **schd** to enter planner mode.
- Tap **new** to begin new record input.
- There are 2 categories. Select the desired category.
- Tap ON: to enter date and tap **OK** to save the setting.
- Tap FROM: to enter starting time and tap **OK** to save the setting.
- Tap TO: to enter ending time and tap **OK** to save the setting.
- Tap NOTE to enter note and tap **OK** to save the new record.

Viewing records

The records are displayed in the following 2 formats:

- In ascending order of date.*
- In alphabetical order of note.*

Touch  to select the display format.

Searching for Records, Editing Records, and Deleting Records

Follow the procedures outline under Phone Book Mode.

Anniversary/Event

To enter anniversary/event mode, press **menu** and tap **^** / **v** or **↑** / **↓** to select ANNIVERSARY then tap **OK**. Screen message “ANNIVERSARY” appears.

Entering new records:

In Anniversary mode, tap **new** to begin new record input.

- There are 2 categories. Select the desired category.
- Tap date to start editing the date and enter date. Tap **OK** to confirm the new date setting or tap **esc** to abort the change.
- Input anniversary or event and tap **OK** to save the new record or tap **esc** to abort the change.

Viewing records:

The records are displayed in the following 2 formats:

- In ascending order of date.*
- In alphabetical order of note.*

Toggle **•••** to select the display format.

- Select the desired category and display format.
- Tap **^** / **v** or **↑** / **↓** to select the desired record.
- Tap **OK** or tap the record directly to read.
- To view characters which are not displayed tap the corresponding line directly.

Searching for Records, Editing Records, and Deleting Records

Follow the procedures outline under Phone Book Mode.

Calculator/ Metric Conversion/ EU Conversion:








Calculator:

- Tap **calc** to enter calculator mode.
- Tap screen-changing key **↵** to get special symbols including %, +/-, MC, MR, M+ and M-.





Metric Conversion:

- During Calculator mode, enter the amount for conversion.
- Tap screen-changing key **↵** to enter conversion mode.
- Tap metric conversion key **↔** to enter the metric conversion mode.
- There are 8 metric conversion units:







KM	< >	MILE	at	1 → 0.62137
HECT	< >	ACE	at	1 → 2.471
ACRE	< >	M2	at	1 → 4,046.94
L	< >	GAL	at	1 → 0.2643
PINT	< >	GAL	at	1 → 0.12499
TON	< >	POUND	at	1 → 2,204.6
GM	< >	OUNCE	at	1 → 0.03527
100°F	< >	°C	at	1 → 37.7778

- Tap t  /  buttons on the side of the PDA to select one of the 8 metric conversions.
- Tap  /  to convert to or from metric unit respectively.
- Example, for 45 mile, how many is Kilometer?
In calculator mode, input 45, tap  , then tap  and select the metric conversion “KM < > MILE”, at last tap  will see the value 72.42061895 on screen.




Currency Setting:

- During Calculator mode, tap screen-changing key  to enter conversion mode.
- Tap currency setting key **SET** to enter the currency-setting mode.
- There are 8 currency conversion units:
 - HM\$1 = OTHER
 - HM\$1 = GBP
 - HM\$1 = YEN
 - HM\$1 = ITA
 - HM\$1 = ESP
 - HM\$1 = FR
 - HM\$1 = SFR
 - HM\$1 = EURO
- Tap  /  to select one of the 8 currency conversions rate, and tap the corresponding rate for inputting a new rate.
- Tap **OK** to save or tap  to quit without saving.



Currency Conversion:

- During Calculator mode, enter the amount for conversion.
- Tap screen-changing key  to enter conversion mode.
- Tap currency conversion key  to enter the currency conversion mode.
- Tap  /  to select one of the 8 currency conversions, as mentioned in B.
- Tap  /  to convert to or from HM\$1 respectively.





- Example, for HM\$1, how much is YEN?




In calculator mode, input 2, tap  , then tap  and select the currency conversion “HM\$1 < > YEN”, at last tap  to see the corresponding value. If the rate is at 1 → 110, the corresponding value 220 will display on screen.

EU Conversion:










- During Calculator mode, enter the amount for conversion.
- Tap screen-changing key  to enter conversion mode.
- Tap EU conversion key  to enter the EU conversion mode.
- There are 8 EU conversion units:

€	< >	BEF	at	1 → 40.3399
€	< >	DEM	at	1 → 1.95583
€	< >	ESP	at	1 → 166.386
€	< >	FRF	at	1 → 6.55957
€	< >	IEP	at	1 → 0.78756
€	< >	ITL	at	1 → 1936.27
€	< >	LUF	at	1 → 40.3399
€	< >	NLG	at	1 → 2.20371

- Tap  /  to select one of the 8 EU conversions.
- Tap  /  to convert to or from EU respectively.
- Example, for EU 100, how much is DEM?

In calculator mode, input 100, tap  then tap  and select the EU conversion “€ < > DEM”, at last tap  will see the value 195.583 on screen.

Count Down:

- To enter count down mode, press  and tap  /  or  /  to select COUNTDOWN then tap . Screen message “COUNT DOWN” appears. This is the Count Down entrance screen.
- Tap  to start editing the time for counting down.
- Enter the desired time for counting down where time is in “HH: MM” format. The maximum time for counting down is 23:59.
- Tap  to confirm the new setting or tap  to abort the change.
- If the input value is not valid, a message “INCORRET” will be shown and return to count down editing screen.
- In Count Down entrance screen, toggle between ON or OFF to switch on/ off the count down time.

- A beep tone will turn on automatically for 35 seconds when the time is counting down to 00:00 and count down is enabled. Tap any key to stop the beep tone.

Expense:

To enter Expense mode, touch **menu** and scroll through the menu choices by tapping **^** / **v** or **↑** / **↓** until you see the Expense prompt. Tap the Expense prompt or **OK**.

Entering new records:

- Tap **exp** to enter expenses mode.
- Tap **new** to begin new record input.
- Select the desired categories.
- Tap date and enter date.
- Tap **OK** to confirm the new setting or tap **esc** to abort the change.
- If the input value is not valid, a message “INCORRECT” will be shown..
- There are 8 payments term:

1. VS—Visa	5. CC—Credit Card
2. MC—Master Card	6. CH—Cheque
3. AX—American Express	7. CA—Cash
4. DI—Diners Club	8. OT—Others
- Tap **^** / **v** or **↑** / **↓** to select one of the payment terms.
- Tap **OK** to confirm the new setting or tap **esc** to abort the change.
- The expenditure of money is classified into 13 types:

1. MEALS	8. FUEL
2. SHOPPING	9. PHONE
3. HOTEL	10. SAMPLE
4. TICKET	11. SOUVENIR
5. TRAIN	12. GIFT
6. TAXI	13. OTHERS
7. RENTAL	
- Tap **^** / **v** or **↑** / **↓** to select one of types.
- Tap **OK** to confirm the new setting or tap **esc** to abort the change.
- Tap \$ to input the amount.
- Tap NOTE to input characters.
- Tap **OK** to save the new record or tap **esc** to abort.

Viewing records:

The records are displayed in the following 2 formats:

- i. *In ascending order of date.*

ii. *In alphabetical order of note.*

- In Expense mode, tap **group** to select the desired category.
- Toggle **⋮** to select the display format.
- Tap **⬆** / **⬇** or **⬆** / **⬇** to select the desired record.
- Tap **OK** or tap the record directly to read.
- To view characters which are not displayed tap the corresponding line directly.

Searching for Records, Editing Records, and Deleting Records

Follow the procedures outline under Phone Book Mode.

Expense Sum:

- In Expense mode, toggle **exp** to view the following screen message:

S: DD-MM-YY

E: DD-MM-YY

TY: ALL

BY: ALL

where S is the starting date

E is the ending date

TY is the money expenditure

BY is the payment term

- Tap the above fields to select and input the desired summing criteria.
- Tap **OK** to display the expense sum.

Web Book / Internet:


To enter the Web Book / Internet mode, touch **menu** and scroll through the menu choices by tapping **⬆** / **⬇** or **⬆** / **⬇** until you see the Web Book / Internet prompt. Tap the Web Book / Internet prompt or **OK**.

Entering new records:

- In Web Book / Internet mode, tap **new** to enter a new record.
- Select the desired category.
- Tap URL to enter web page address.
- Tap NOTE to enter description.
- Tap **OK** to confirm the new record or tap **esc** to abort.

Viewing records:

The records are displayed in the following 2 formats:


- i. *In alphabetical order of address.*
- ii. *In alphabetical order of note.*
- Toggle  to select the display format.

Searching for Records, Editing Records, and Deleting Records

Follow the procedures outline under Phone Book Mode.

Spell Check:

To enter spell mode, tap ABC.





- In Spell mode, enter word and tap  to start checking.
- If the word is correct, a message “CORRECT” shown.
- If the word is incorrect, related words and the corresponding number of words found are shown.

The following screen message is displayed

FOUND XX
?????

XX-the number of corresponding words found

?????-the related word

- To view characters which are not displayed owing to the restriction of the screen width, tap  /
 or  /  for off-screen characters.

Translator:

- Tap  to enter translator mode.


Screen message shown in the following format





S: ENGLISH
T: ITALIANO
INPUT STRING

Where S stands for source word and T stands for target word.







- There are 7 languages for translation:

ENGLISH
ITALIANO
DEUTSCH
FRANÇAIS
ESPAÑOL
PORTUGUÊS
NEDERLANDS

- Tap S and T to select source and target language.
- Enter the word for translation, Tap  to start translation. Maximum length is 11 characters.
- The first line shows the inputted or corresponding source word, the second line shows the translated word.

- Tap  /  to see the additional translated word if they are present.
- To view characters which are not displayed owing to the restriction of the screen width, tap  /  for off-screen characters.

Memory:





To enter memory mode, press  and tap  /  or  /  to select MEMORY then tap . Screen message “MEMORY” appears.

- In Memory mode, user can see the number of records store in 7 applications and the total memory used. The following is the screen message:







SCHD	N1
PHONE	N2
TO DO	N3
ANNIV	N4
MEMO	N5
EXPENSE	N6
WEB	N7
MEMORY	XXX%

where N1- N7 are the numbers of records store in each application




XXX is the total memory used

- Tap  /  or  /  to view the above applications and the memory used.




Password:

To enter password mode, press  and tap  /  or  /  to select PASSWORD then tap . Screen message “NEW PASSWORD” appears.

Setting Password:

- In password mode, carefully input a desired password which consists of maximum 8 letters. Remember this password well. Tap  to confirm the input.
- Message “RE-ENTER” appears .
- Carefully input the same password again. Tap  to save the password.
- If the second input matches with the first input, the unit returns to the memo screen and the icon  is displayed. Otherwise, message “INCORRECT!” is displayed.

Deleting the Password:

- If a password is set and the user wants to delete it, enter Password mode and message “PASSWORD” appears.
- Enter the correct password and tap .
- If correct password is entered, the screen message “NEW PASSWORD” appear, tap  to confirm deletion or tap  to abort delete.

Changing the Password:

- If a password is set and the user wants to change it, enter Password mode and message “PASSWORD” appears.
- Enter the correct password and tap **OK**.
- If correct password is entered, the screen message “NEW PASSWORD” appear, enter the new password as described above.

System

To enter system mode, press **menu** and tap **^** / **v** or **↑** / **↓** to select SYSTEM then tap **OK**.
Screen message “SYSTEM” appears.

- In System mode, user can change the following items:

Language Prompt
Screen Contrast
Date Format
Hour Format
Auto Power Off
Key Tone

- Tap **^** / **v** or **↑** / **↓** to select the desired item.
- To change language prompt, tap ENGLISH to enter the language-editing mode. There are 7 language prompt message to select:

ENGLISH
ITALIANO
DEUTSCH
FRANÇAIS
ESPAÑOL
PORTUGUÊS
NEDERLANDS

- Tap **^** / **v** or **↑** / **↓** to select the desired language.
- Tap **OK** to confirm the new setting or tap **esc** to abort.
- There are 10 levels of screen contrast to adjust, tap the contrast bar to adjust.
- To change date format, toggle between M/D/Y and D/M/Y to change the date format.
- To change hour format, toggle between AM/PM and 24HR to change the hour format.
- Select a value within 1 to 5 to define the auto power off time.
- Toggle between ON and OFF to switch on or off the key tone.
- Tap **OK** to confirm the new setting or tap **esc** to abort.

Game

To enter game mode, press **menu** and tap **^** / **v** or **↑** / **↓** to select GAME then tap **OK**.
Screen message “GAME” appears.

Hangman Game:

- The user is required to guess the word with only the length of the word given initially.
- Enter letters which may be contained within the word. If the guess is correct, the letter will be shown on the screen in its appropriate position(s) within the word.
- The user will win the game if the entire word is guessed correctly within 9 attempts.

Defrag

Perform this optimization regularly in order to fully utilize the memory. The defragmentation process might take a few minutes. Once the procedure is started, do not turn the unit OFF. The unit will not accept any input while the memory optimization is processing. The screen will automatically return to the Menu screen after finishing the process.

Synchronizing Data with Your PC

1. Install the PDO Desktop software from the included CD Rom. The installation routine should start automatically when you insert the supplied CD into your PC.
2. After installation you will have two shortcuts on the PC Desktop. They are labeled PDO Desktop and SmartSync.
3. SmartSync must now be configured to work to your PC. To configure SmartSync double click on the SmartSync desktop shortcut. SmartSync will launch and appear in the lower right corner of the PC screen in the system tray.
4. Right click on the SmartSync icon and select SmartSync Settings. Here you can select the appropriate Comport (COM1, COM2, etc) for your PC. Select the correct port and Click on Apply and OK.
5. SmartSync must appear in the system tray in order for the synchronization process to function. You will have to manually start the SmartSync process unless you have selected the "Load SmartSync automatically when computer starts" option in SmartSync Settings.
6. Connect the provided cable between the PC Comport and the Extreme3 making sure to fit the cable snugly into the Extreme3.
7. On the Extreme3 go to the Menu and scroll down to "Link". Click OK on Link and then answer "Yes" to initiate the sync procedure.
8. You will see the sync process start on the PC and "In Progress" will appear on the Extreme3. When successfully finished a message will appear on the PC, "Sync OK" and on the Extreme3 you will see "Success".